

PowerMust Office 650



Features

- Surge-type UPS for home and office use
- Microprocessor control for high reliability
- Built-in USB port
- Protection for modem, phone line & network
- Audible alarm in case of abnormal conditions
- Free software-CD
- Intelligent battery management
- Easy handling





PowerMust Office 650

Specification

Product type	Uninterrupted power supply; Offline / surge protection
Model	PowerMust Office 650
Capacity	650 VA / 390W
Input	000 VA / 000VV
Phase	Single
Voltage	120 VAC or 220 / 230 / 240VAC
Voltage range	99~141 VAC // 182~258 / 190~270 / 198~282 VAC
Frequency	50 / 60Hz
Frequency range	45~55 Hz // 55~65 Hz
Output	10 0011211 00 00112
Phase	Single
Voltage	120 VAC or 230 VAC
Voltage regulation (Batt. mode)	± 10%
Frequency	50 Hz or 60Hz
Frequency regulation (Batt. mode)	±1Hz
Output waveform (Batt. mode)	Modified Sinewave
Power factor	0.6
Battery	0.0
Battery type & number	12V7Ah * 1 pc
Back up time (at a PC load with 15"	
monitor)	20 minutes
Back up time (at a PC load with 17"	
monitor)	16 minutes
Recharge time	24 hours up to 90 % after complete discharge
Transfer time	
Typical	2~6 ms
Indicator	
AC mode	Green LED lighting
Battery mode	Orange LED flashing every 10 seconds
Low battery at battery mode	Red LED lighting
Fault	Red LED lighting
Battery weak at AC mode	Red LED lighting
Battery fault at AC mode	Red LED lighting
Overload	N/A
Audible alarm	
Battery mode	Sounding every 10 seconds
Low battery at battery mode	Sounding every second
Fault	Continuously Sounding
Battery weak at AC mode	N/A
Battery fault at AC mode	N/A
Battery replacement	Sounding every 2 seconds
Overload	N/A
Protection	
Full protection	Deep Discharge, OverCharge, Short Circuit Protection RJ 11 Modem/Telephone Protection *3
Physical	
Dimension, D*W*H (mm)	297*192*90
Net weight (kgs)	6.2
Schuko type	4 outlets (1 for surge protection, 3 for battery backup)
Environment	
Operating Environment	0~40 °C, 20~90% relative humidity (non-condensing)
Noise Level	Less than 40dB
Interface	
Smart RS-232	Windows family, Linux, Sun Solaris, IBMAix, Compaq True64, SGI IRIX, FreeBSD, HP-UX, and
	MAC
USB Port	Windows 98/2000/ME/XP
Accessories	USB cable, RS232 cable, Application CD, User guide